

Правая боковина

Цепи переменного тока комплекта 01				
01.SG1-2	01X1	1	○	A421-2T
	01X2	2	○	
01.SG1-4	01X3	3	○	B421-2T
	01X4	4	○	
01.SG1-6	01X5	5	○	C421-2T
	01X6	6	○	
01.SG1-8	01X7	7	○	N421-2T
	01X8	8	○	
		9		
		10		
01.SG2-2	01X11	11	○	
	01X12	12	○	
01.SG2-4	01X13	13	○	
	01X14	14	○	
01.SG2-6	01X15	15	○	
	01X16	16	○	
01.SG2-8	01X17	17	○	
	01X18	18	○	
		19		
		20		
01.SG3-2	01X21	21	○	A491-2T-1
	01X22	22	○	
01.SG3-6	01X23	23	○	B491-2T-1
	01X24	24	○	
01.SG3-10	01X25	25	○	C491-2T-1
	01X26	26	○	
01.SG3-4	01X27	27	○	A491-2T-1
	01X28	28	○	
01.SG3-8	01X29	29	○	A491-2T-1
	01X30	30	○	
01.SG3-12	01X31	31	○	N491-2T-1
	01X32	32	○	
		33		
		34		
01.SG4-2	01X35	35	○	A491-2T-2
	01X36	36	○	
01.SG4-6	01X37	37	○	B491-2T-2
	01X38	38	○	
01.SG4-10	01X39	39	○	C491-2T-2
	01X40	40	○	
01.SG4-4	01X41	41	○	A492-2T-2
	01X42	42	○	
01.SG4-8	01X43	43	○	A493-2T-2
	01X44	44	○	
01.SG4-12	01X45	45	○	N491-2T-2
	01X46	46	○	
		47		H661-4
		48		K661-4
01.SG5-2	01X49	49	○	A661-2
	01X50	50	○	
01.SG5-4	01X51	51	○	B661-2
	01X52	52	○	
01.SG5-6	01X53	53	○	C661-2
	01X54	54	○	
		55		N661-2
		56		
01.SG6-2	01X57	57	○	A661 - 4
	01X58	58	○	
01.SG6-4	01X59	59	○	B661 - 4
	01X60	60	○	
01.SG6-6	01X61	61	○	C661 - 4
	01X62	62	○	
		63		N661-4
Цепи питания комплекта 01				
01.SF1-4	01X64	64	○	1* -2T
	01X65	65	○	
		66		
01.SF1-2	01X67	67	○	2* - 2T
	01X68	68	○	
Оперативные цепи комплекта 01				
01.SF1-3	01X69	69	○	1 - 2T
01.E1-XP1-(+)	01X70	70	○	
01.GB1-L(+)	01X71	71	○	
01.GB2-L(+)	01X72	72	○	
01.SG1-12	01X73	73	○	
A1-XT10:2	01X74	74	○	
		75		
A1-XT6:4	01X76	76		F-31
A1-XT6:5	01X77	77		35 - 2T
A1-XT3:1	01X78	78		10 - 2T
A1-XT3:3	01X79	79		11 - 2T
A1-XT3:5	01X80	80		12 - 2T
A1-XT3:7	01X81	81		13 - 2T
A1-XT3:9	01X82	82		14 - 2T
A1-XT3:11	01X83	83		15 - 2T
A1-XT3:13	01X84	84		16 - 2T
A1-XT3:15	01X85	85		17 - 2T
	01X86	86		
A1-XT5:3	01X87	87		19 - 2T

A1-XT3:1		01X78	168		
A1-XT3:3		01X79	169		
A1-XT3:5		01X80	80		
A1-XT3:7		01X81	81		
A1-XT3:9		01X82	82		
A1-XT3:11		01X83	83		
A1-XT3:13		01X84	84		
A1-XT3:15		01X85	85		
		01X86	86		
A1-XT5:3		01X87	87	19 - 2T	
A1-XT5:5	01.KL2-11	01X88	88		
A1-XT5:7	01.KL3-11	01X89	89		
			90		
A1-XT5:9		01X91	91	25 - 2T	
A1-XT5:11		01X92	92	27 - 2T	
A1-XT5:13		01X93	93	29 - 2T	
A1-XT5:15		01X94	94	31 - 2T	
A1-XT5:17		01X95	95	33 - 2T	
A1-XT3:2	01X96	96	○	2 - 2T	
01.SF1-1	01X97	97	○		
01.E1-XP1-(-)	01X98	98	○		
A1-XT5:6	01X99	99	○		
Цепи газовой защиты комплекта 01					
01.SF2-3	01X100	100	○	3* - 2T	
	01X101	101	○		
01.SF2-4	01X102	102	○	3 - 2T	
	01X103	103	○		
01.A2-X1	01X104	104		21 - 2T	
01.A3-X1	01X105	105		23 - 2T	
01.SF2-2	01X106	106	○	4 - 2T	
01.KL2-13	01X107	107	○		
01.SF2-1	01X108	108	○	4* - 2T	
	01X109	109	○		
Контрольный выход комплекта 01					
A1-XT4:13	01X110	110			
A1-XT4:14	01X111	111			
Выходные цепи комплекта 01					
01.SA10-14	01X112	112			
01.SA11-14	01X113	113			
01.SA10-18	01X114	114			
01.SA11-18	01X115	115			
01.SA12-14	01X116	116		301-1	
01.SA13-22	01X117	117		301-2	
01.SA10-6	01X118	118		101 - 2T	
01.SA10-10	01X119	119		201 - 2T	
01.SA11-6	01X120	120			
01.SA11-10	01X121	121			
01.SA12-6	01X122	122			
01.SA13-6	01X123	123			
01.SA13-10	01X124	124			
01.SA13-14	01X125	125			
01.SA4-2	01X126	126			
01.SA4-6	01X127	127			
A1-XT11:10	01X128	128		A1	
A1-XT11:13	01X129	129		B1 - 2	
01.SA12-10	01X130	130		301-1	
01.SA13-18	01X131	131		301-2	
A1-XT12:4	01X132	132			
A1-XT12:7	01X133	133			
A1-XT12:10	01X134	134			
A1-XT8:9	01X135	135			
		136			
A1-XT4:2	01X137	137			
A1-XT4:4	01X138	138			
A1-XT4:6	01X139	139			
A1-XT4:8	01X140	140			
A1-XT4:10	01X141	141		025-1	
A1-XT4:12	01X142	142		025-2	
A1-XT7:3	01X143	143		133 - 2T	
A1-XT7:5	01X144	144			
A1-XT7:6	01X145	145		233 - 2T	
A1-XT7:8	01X146	146			
A1-XT7:9	01X147	147			
A1-XT7:11	01X148	148			
A1-XT7:12	01X149	149			
A1-XT7:14	01X150	150			
A1-XT7:15	01X151	151			
A1-XT7:18	01X152	152			
A1-XT8:3	01X153	153			
A1-XT8:6	01X154	154			
A1-XT11:3	01X155	155			
A1-XT11:6	01X156	156			
A1-XT11:9	01X157	157		A7	
A1-XT11:12	01X158	158		B15 - 2	
A1-XT11:15	01X159	159		023-1	
A1-XT11:18	01X160	160		023-2	
A1-XT12:3	01X161	161		B17 - 2	
A1-XT12:5	01X162	162		Резерв	
A1-XT12:6	01X163	163			
A1-XT12:8	01X164	164			
A1-XT12:9	01X165	165		Резерв	
A1-XT12:11	01X166	166		Резерв	
A1-XT8:11	01X167	167		Резерв	
		168			
		169			
		170			
		171			
		172			
Выходные цепи газовой защиты комплекта 01					

